

Maintenance-Free AGM Motorcycle Battery

No.	Type	Cap.	Overall Dimensions (mm)				Layout	A Class	B Class
		(Ah)	L	W	H	TH		(Kgs)	(Kgs)
1	YT4 MF	4	112.5	68.7	87.3	87.3		1.48	1.30
2	YT4L MF	4	112.5	68.7	87.3	87.3		1.48	1.30
3	12N5 MF	5	119.3	60.3	128.6	128.6		1.9	1.70
4	12N5 MF	5	119.3	60.3	128.6	128.6		1.9	1.70
5	12N6.5 MF	6.5	137.4	65.2	101.3	101.3		2.05	1.90
6	12N6.5L MF	6.5	137.4	65.2	101.3	101.3		2.05	1.90
7	YT7 MF	7	149.5	85.5	93.6	93.6		2.45	2.37
8	YT7L MF	7	112.5	68.7	132.3	132.3		2.4	2.25
9	12N7 -3A MF	7	148.3	58.8	129	129		2.4	2.20
10	12N7 -3AL MF	7	148.3	58.8	129	129		2.4	2.20
11	YT5 MF	5	112.5	68.7	105.7	105.7		1.8	1.70
12	YT5L MF	5	112.5	68.7	105.7	105.7		1.8	1.70
13	12N9 MF (126)	9	136.5	76.8	123.1	123.1		2.53	2.37
14	12N9L MF (126)	9	136.5	76.8	123.1	123.1		2.53	2.37
15	12N9 MF (133)	9	136.8	76.8	134.6	134.6		2.64	2.35
16	12N9L MF (133)	9	136.8	76.8	134.6	134.6		2.64	2.35
17	YT9 MF	9	149.5	85.5	107	107		3.05	2.88
18	YT12 MF	12	149.5	85.5	131.3	131.3		3.6	3.22
19	YT12L MF	12	149.5	85.5	131.3	131.3		3.6	3.22
20	YT14L MF	14	149.5	85.5	146.7	146.7		3.66	3.3
21	32A-F	32	187	125	174	174		6.5	6.1
22	36A-F	36	195	127	200	220		8.8	

Note The above data are average values, and can be obtained within 3 charge/discharge cycles. These are not minimum values. Cell and battery designs/specifications are subject to modification without notice. Contact **Toasan** for the latest information

TERMINAL TYPES

Terminal shapes vary from one battery to another. By identifying the correct replacement battery from the listing in this book, you are assured of the proper terminal configuration. For custom applications, refer to the following chart to identify terminal shape and corresponding batteries.

Type	Terminal				Battery Type				
	Illustration	Front	Side	Top					
1					YB7C-A YB14L-A1	YTX16-BS-1			
2					YB9L-A2 12N5.5-4A YB16AL-A2				
3					12N24-3 Y60-N24-A	12N24-3A			
4					GYZ20L YB30L-B YTX15L-BS YTX20L-BS	Y50-N18L-A3 Y1X30L-BS YTX16-BS YTX24HL-BS	YB12C-A Y1X30L-BS-PW YTX20-BS YTX20HL-BS	YB16B-A YTX14AHL-B YTX20H-BS Y1X20HL-BS	YB30CL-B YTX14AH-BS YTX20HL-BS-PW
5					GYZ16H GYZ16HL YB4L-B YTX14L-BS	YTX7L-BS KMX14-BS YT12A-BS YTX20CH-BS	YTX9-BS YB16C-B YTX12-BS YTX4L-BS	YTZ5S YTZ7S YB16CL-B YTX14-BS	YTX5L-BS YB4L-A YTX14H-BS YTX7A-BS
6					YB3L-A YB7L-B YB12A-A YB16-B 12N5-3B 12N7-4A 12N9-4B-1 6N6-3B B54-6	YB3L-B YB9A-A YB12AL-A YB-16-B-CX 12N5-4B 12N7-4B 12N10-3A 6N6-3B-1 B38-6A	YB5L-B YB9-B YB12AL-A2* YB16L-B 12N5.5-3B 12N7D-3B 6N11A-1B	YB7-A YB9L-B YB12A-B YB16HL-A-CX 12N5.5A-3B 12N12A-4A-1 6N11-2D	YB7B-B YB10L-B YB14A-A1 SYB16L-B 12N7-3B 12N9-3B 6N12A-2D B39-6
7					HYB16A-AB Y50-N18A-A	YB16B-A1** Y50-N18L-A	YB18-A Y50-N18L-A-CX	YB18L-A SY50-N18L-AT	
8					YB10A-A2 YB14-A2 YB14-B2 12N14-3A	YB10L-A2 YB14A-A2 YB14L-B2	YB10L-B2 YB14L-A2	YB12B-B2 SYB14L-A2 12N11-3A-1	
9					YHD-12H				
10					51814	51913	53030	YT19BL-BS	
11					YT9B-BS YT7B-BS	YTZ10S	YTZ12S YT12B-BS	YTZ14S	YT14B-BS
					Note: Terminal is Brass Plated Steel				
12					YTR4A-BS				
13					YT4B-BS				
14					GYZ20H GYZ20HL	GYZ32HL			
					Note: Encapsulated Brass Nut				

* Includes terminal adapter for converting to top mount
 ** Includes terminal adapter for converting to side mount

Yuasan Battery manufacturer Co., Ltd

South Of Lianfa Avenue, Huiqiao Industrial Park,
 Tongqiao Town, Huizhou, Guangdong, China
 Tel:+86-0752-3198012 Email:export@yuasan.cn



<https://www.yuasan.cn/>